

Western Instruments

Established 1965

26509 Township Road 543
Sturgeon County, Alberta
T8T 1M1 Canada

Phone: (780) 459-6720
Fax: (780) 459-7837
E-Mail: info@westerninstruments.com

Web: www.westerninstruments.com

WE-7-CDM Kit (Complete Dry Method)



Ready to go



W-CDM Kit Illustrated
with a WE-7 Yoke.
(WE-7-CDM)

Western's MPI Kits are offered in a great variety of configurations. Our Complete Dry Method Kit is supplied in our standard #3 Case (above). The model illustrated above is a WE-7-CDM Kit (Complete Dry Method) which includes the following items;

- WE-7, AC Yoke
- W-PT, 10 Pound Pull Test Bar
- W-FI, Field Indicator (Magnetometer)
- Operator Instructions
- #3 Carrying Case (16"x12"x4.5")
- Powder Bulb
- Calibration Certificate
- 4x ¾ Pounds (350g) of Dry Method Powder: Grey, Red, Black & Yellow

The W-WD Kit can be supplied with any model of AC Yoke, with our custom fitted Carrying Case. The W-CDM Kit is Ideal for a Certified MPI Inspector, to ensure compliance to a documented Inspection Specification for Dry Method Inspection, including ASTM E1444

Phone: (780) 459-6720 Fax: (780) 459-7837 Web: www.westerninstruments.com E-Mail: info@westerninstruments.com