

Western Instruments

Established 1965

26509 Township Road 543
Sturgeon County, Alberta
T8T 1M1 Canada

Phone: (780) 459-6720
Fax: (780) 459-7837
E-mail: info@westerninstruments.com

Web: www.westerninstruments.com

Standard Pit Gauge April 15, 2017

Model Description		
Model	Part #	Description
Lever Type Pit Gauge		
Tri-Gauge	N88L-1	Lever Type Pit Gauge for Evaluation of Corrosion (0.010" Res.)
Jr. Tri-Gauge	N88L-2	Lever Type Pit Gauge for Evaluation of Corrosion (0.005" Res.)
Tri-Weld Gauge	N88L-3	Multi-Function Weld Fit-up and Inspection Gauge (see literature)
Dial Indicator Pit Gauge		
Basic	N88-2	Centre mount 2¼" (57mm) Blade, our most Popular Gauge
Basic Plus	N88-3	Centre mount 3¼" (82mm) Blade
Pocket	N88-4	Dual Edge Blade (reversible). 1.5" (38mm) long and spot base
Reaching	N88-5	4¾" (121mm) Blade. End Mount, with long Nose Cut-out.
Reaching Plus	N88-6	6" (152mm) Blade. Same as Reaching but Longer.
Special Reaching Plus	N88-6S	Same as Reaching Plus but has the extra Dial Indicator Center mount hole as well.
Basic Plus Magnetic	N88-3M	Centre mount 3¼" (82mm) Blade c/w Two (2) adjustable magnet cartridges.
Reaching Magnetic	N88-5M	End Mount 4 3/4" (121mm) Blade, c/w Two (2) adjustable magnet cartridges.
Reaching Plus Magnetic	N88-6M	End Mount 6" (152mm) Blade, c/w Two (2) adjustable magnet cartridges.
Reference Gauge	N88-12	5.5" (140mm) long, 3/4" (19mm) wide with Inverted V Edge, 2 adjustable magnet cartridges. Similar and interchangeable with Bridging Pit Gauge Main Blade. Also available as Bridging Reference Gauge- See Kit Price list.
Accessories		
Fasteners and Wrench Kit	N88-K	Set Screw type Magnet for N88-3M, 5M,6M, and N88-12
Contact Points		
#1-Standard Tip	Ø0.040" Dia. point	N88-S General Corrosion

#2-Conical Tip	Ø0.010" Dia. point	N88-C	Corrosion Coupons
#3-Needle Tip	Ø0.005" Dia. point	N88-N	Very Fine Pits
Extension	0.50"- 12.7mm	N88-X	Extends length of contact point 0.05" (12.7mm)
Small Wooden Carrying Case	N88-WS	Small Wooden Carrying Case for all Dial Indicators, Basic, and Pocket Pit Gauges.	
Large Wooden Carrying Case (Reaching)	N88-WB	Wood Carrying Case used for Reaching, Reaching Plus, with cust outs for most Kits	
Dial Indicators			
Imperial	N88-I 0 to 0.500" Range, in 0.001" Increments		
Metric	N88-M 0 to 10mm Range, in 0.01 mm Increments		
Digital	N88-D0 to 0.500"/0 to 10mm Range - Imperial or Metric Readings		
Software and Cable	N88-DI Interface to Computer		